

# Befestigungsvarianten

 <p>A technical cross-section drawing of a chamfered flat anchor. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a chamfered top edge and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>	 <p>A technical cross-section drawing of a standard flat anchor. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a straight top edge and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>	 <p>A technical cross-section drawing of a flat anchor with a guide. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a straight top edge and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>	
<p>gekröpfter Flachanker mit Führungshilfe</p>	<p>Flachanker</p>	<p>Flachanker mit Führungshilfe O1</p>	
 <p>A technical cross-section drawing of a flat anchor with a guide. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a straight top edge and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>	 <p>A technical cross-section drawing of a flat anchor with a guide. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a straight top edge and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>	 <p>A technical cross-section drawing of a Z-anchor. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a Z-shaped profile and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>	 <p>A technical cross-section drawing of a bracket. The anchor is shown in a hole, with a blue line representing the guide wire. The anchor has a bracket-like profile and a hook-like end. The guide wire is inserted from the top, passes through the anchor, and is hooked at the bottom.</p>
<p>Flachanker mit Führungshilfe O2</p>	<p>Flachanker mit Führungshilfe O3</p>	<p>Z-Anker METEX 03</p>	<p>Lasche METEX 04</p>